




M-218-11R

Replaces M-218-08, M-218-08R and M-218-11

Troubleshooting Guide

Chipspreaders



E. D. ETNYRE & CO.

Troubleshooting Guide

Chipspreaders

M-218-11R

Contents

Speed sensor error (failure).....	2
Fuel sender alarm.....	4
Low oil pressure alarm.....	5
Water temperature alarm.....	7
Hydraulic oil temperature alarm.....	9
Gate sensor failure alarm (Rexroth Computer).....	10
Checking solid state gate transducer.....	12
Gates open / close faster than other side.....	13
Air gates out of adjustment (very loud noise as master power is turned on / off).....	15
Spreadroll speed fluctuating.....	17
Hydraulic Stand-by (load sense) pressure is fluctuating (needle not steady on gauge).....	19
Overlap or streak in center when hoppers are fully extended.	20
No gradability	22
Auxiliary hydraulic pressure will not relieve.....	23
Gates will not operate (Hydraulic buss bar)	25
Starter Cranks But Does Not Start	26
Emergency Driveline Disengage Procedure	27
<i>Computer Wiring Connections</i>	29
MDC Faults with version 3-52 software.....	30
Joystick Adjustments:	
Machine come to stop while moving	31
Machine will not go in reverse	31
Problem: Machine will not move forward and/or in reverse, after Rexroth Computer Update is completed.....	32



E.D ETNYRE & CO.

1333 S. Daysville Road, Oregon, IL 61061

Phone: 1-800-995-2116

Fax: 815-732-7400

Web Site: www.etnyre.com

For further assistance call Etnyre service department at (1800-995-2116).

Problem # 1

Speed sensor error (failure)

Check to make sure joystick is in neutral (alarm will sound if joystick is out of neutral and machine does not move).

- 1) Check fuses or circuit breakers
- 2) Check speed sensor
 - a) Check for loose sensor
 - b) Poor alignment (see figure # 1A & 1B)
 - c) Improper clearance- 1/16" recommended
 - d) Loose wiring connection
 - e) Pinched or rubbed wiring
- 3) Check wiring from computer to speed sensor (with harness disconnected).
 - a) Red wire (12 VDC)
 - b) Black wire (ground)
 - c) Clear or white wire (signal 9-10 VDC)
 - d) Shield (ground)

If voltages and grounds are (OK), proceed with step # 4

If voltages and grounds are (NOT OK), proceed with step # 5
- 4) Check power at speed sensor (with harness connected)
 - a) Red wire (12 VDC)
 - b) Black wire (ground)
 - c) Clear or white wire (signal 4-7 VAC while machine is moving) No signal, replace speed sensor
 - d) Shield (ground)
- 5) Check connections at computer (with speed sensor disconnected)

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

- a) P1-PIN 21 (speed sensor power 12 VDC)

If voltage is (OK) but no voltage was present in step # (3a) check wiring between computer and speed sensor for continuity. If no continuity is present, replace harness asm.

No voltage - bad connection or bad computer output.

- b) Ground (attached to computer base)

Problem # 1 continued

c) P3-PIN 10 (9-10 VDC)

If voltage is (OK) but no voltage was present in step (3c) check wiring between computer and speed sensor for continuity. If no continuity is present, replace wiring harness asm.

If NO voltage is present, check voltage on other end of pull-up resistor attached to (P3-PIN10). Should be (12 VDC). If you have (12 VDC), replace resistor (1k OHM)

d) Ground (attached to computer base)

SPICER AXLES




Figure 1A

- 1) Mag pick-up
- 2) Pick-up gear




Figure 1B

KESSLER AXLES




Figure 1C

- 1) Mag pick-up

Speed Sensor for Kessler Axles

Part No. 6703670




Figure 1D

Problem # 2

Fuel sender alarm

- 1) Check fuel level. If not low on fuel proceed with step #2.
- 2) Check for debris lying on top of sending unit (metallic).
- 3) Check wiring connection for loose or bad connection (frayed wire touching ground).
- 4) Disconnect wire from sending unit.

If alarm quits: (see figure #2 for resistance values)

If alarm persists: proceed to step #5.

- 5) Check wiring between sender and computer.
- 6) Check connection at computer (loose connector).
- 7) Check connection at computer terminal (P2-PIN19)

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

Arm Angle (degrees)	Ohms	Display Reading (%)	Gallons Remaining (total)	Gallons Remaining (useable)
50.00	250	100	68	65
45.20	240	100	65	62
39.58	227	95	57	54
34.38	216	90	54	51
29.49	206	85	52	49
24.82	196	80	50	47
20.32	186	75	46	43
15.95	176	70	43	40
11.68	167	65	41	38
7.47	158	60	38	35
3.30	149	55	35	32
-0.86	140	50	32	29
-5.01	131	45	30	27
-9.20	122	40	27	24
-13.43	113	35	24	21
-17.74	104	30	21	18
-22.16	94	25	18	15
-26.72	84	20	16	13
-31.47	74	15	13	10
-36.48	63	10	10	7
-41.83	52	5	7	4
-47.70	39	0	5	2
-50.00	34	0	4	1

Figure 2

Problem # 3

Low oil pressure alarm

- 1) Install a mechanical gauge and verify engine oil pressure (approx 30 psi @ idle, 65 psi @ full rpm, with engine coolant at operating temperature 160° - 190°F)
- 2) Check wiring at sensor for bad or loose connection.
- 3) Ground sensor wire to engine block to see if alarm quits.
If alarm quits, see calibration chart below for resistance values.
If alarm persists, proceed to step #4.
- 4) Check computer connector P2 and P3.

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 24

- 5) Check connections at computer
Oil pressure sender (P2-PIN18)
Oil pressure ground (P2-PIN2)
- 6) Look for wires pulled out, touching or possibly disconnected.
- 7) Check continuity of wiring between computer and oil pressure sender.
- 8) Install new oil pressure sender unit with OEM replacement. (Resistance values have to be correct for oil pressure to work properly)

Important Information:

Alarm activated: 5 psi @ 1400 R.P.M.and below
 10 psi @ 1401 R.P.M.and above
(Above readings must exist for (2) two seconds for alarm to activate).

See figure # 3 on page # 6 for proper resistance values.

Display Reading (P.S.I.)	Ohms (min)	Ohms (nominal)	Ohms (max)
0	225	240	257
5	210	223	240
10	196	217	224
15	183	192	209
20	171	179	194
25	160	167	180
30	150	156	168
35	142	146	156
40	134	137	146
45	126	128	136
50	120	121	127
55	113	113	117
60	106	106	106
65	100	100	100
70	93	93	93
75	87	87	87
80	82	82	82
85	76	76	76
90	72	72	72
95	66	66	66
100	60	60	60
105	54	54	54
110	50	50	50
115	44	44	44
120	38	38	38
125	33	33	33

Figure 3

Problem # 4

Water temperature alarm

1) Check and verify coolant is exceeding 240°F using laser probe or mechanical temperature gauge.

 If coolant is not hot, proceed with step #2

 If coolant is exceeding 240°F, proceed to step #7

2) Check wiring terminal at sensor (loose or bad connection).

3) Check wiring.

 a) frayed wiring

 b) bare wiring

4) Disconnect sensor and check to see if alarm quits

 If alarm quits (See figure # 4 page #8 for resistance values).

 If alarm persists continue with step #5.

5) Check for loose or bad connection at computer (P2)

6) Check wiring from sensor to computer

 computer connection (P2-PIN20)

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

7) Check engine coolant level (using caution while taking off radiator cap.)

8) Check and clean out any debris in front of radiator.

9) Check to see if radiator and/or hydraulic cooler is plugged up with aggregate dust and/or particles. (Clean if this condition exists)

10) Check for any leaks in cooling system. (Leaks will allow particles to collect).

11) If overheating condition persists, investigate further into radiator and/or engine problem.

Ohm Range (min)	Ohm Range (max)	Display Reading (temperature °F)
	325	100
296	324	105
266	295	110
236	265	115
211	235	120
185	210	125
168	184	130
152	167	135
138	151	140
125	137	145
111	124	150
101	110	155
94	100	160
86	93	165
81	85	170
74	80	175
68	73	180
64	67	185
58	63	190
55	56	195
52	54	200
47	53	205
44	46	210
41	43	215
37	40	220
34	36	225
29	33	230
28	28	235
26	27	240

Figure 4

Problem # 5

Hydraulic oil temperature alarm

- 1) Check oil level.
- 2) Verify that temperature of hydraulic oil is over 180° F, using laser probe or mechanical temperature gauge.
 - If temperature is above 180°F, continue with Step #3.
 - If temperature is below 180°F, skip to Step #9.
- 3) Check for filter restriction (gauges located on filter bases). If gauge is damaged or broken it should be replaced.
- 4) Check for debris trapped in front of hydraulic cooler. (Debris indicates possible leak in hydraulic or cooling system).
- 5) Check for debris trapped between the hydraulic cooler and engine radiator. (Debris indicates possible leak in hydraulic or cooling system).
- 6) Try to identify source of heat generation, (relief-manifold-block-quick coupling-hydraulic fitting-hose).
- 7) Check to see if hydraulic system is plumbed properly (especially thru the hydraulic cooler).
- 8) ..Check hydraulic pressures to ensure that they are not above the allowable limits. (Ref: Problem #14)
- 9) . Check connection at temperature sensor (on hydraulic reservoir tank) for a loose or bad connection.
- 10) Disconnect sensor wire to see if alarm quits.
 - If alarm quits see chart below for resistance values.
 - If alarm persists continue with Step #11.
- 11) Check connection at computer (Plug –P2).

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

- 12) Check wiring from sensor to computer (P2-PIN17)
- 13) Check wiring for short to ground

See figure # 4 page # 8 for proper resistance values.

Problem # 6

Gate sensor failure alarm (Rexroth Computer)

- 1) Check gate transducer on side indicated by digital display.
- 2) Check for plug disconnected at sensor.
 - a) Broken or pinched wiring
 - b) Bad, corroded or loose connection
- 3) Check transducer (fixed or variable hopper) potentiometer type see # 4.

For units with solid state transducer (wiring color code red-blue-black)

- a) Make sure that gate is fully closed.
- b) Do not unplug sensor from harness (this sensor is checked by voltage related to sensor position).

Adapter (Etnyre part # 7050350) is available so that tapping into and stripping wires is not needed.

- c) Check voltage on red wire terminal (voltage supplied to transducer) ground using black wire terminal. Reading should be (5.0 VDC).
- d) Check voltage on the blue wire terminal (transducer signal voltage) ground using black wire terminal. Reading should be between (0.5 – 1.5 VDC). Ideal setting (1.0 VDC).
- e) Make adjustment by rotating transducer if not within these parameters.

See figure # 5 for proper adjustment procedure.

- f) Re-calibrate (null/scale) gate calibrations in computer set-up if adjustment was made.

Material will need to be re-calibrated if transducer is adjusted.

For units with resistor type potentiometer (wiring color code orange-green-black)

- 4) Adjusting potentiometer (old type)
 - a) Make sure that gate is fully closed.
 - b) Unplug sensor from harness
 - c) Check OHMS across the orange and green wire terminals at the connector attached to the potentiometer.
 - d) Reading should be between (250 – 270 OHMS).
 - e) Make adjustment if not within these perimeters.
 - f) Re-calibrate (null/scale) gate calibrations in computer set-up if adjustment was made.

Problem # 6 continued

NOTE: OHMS increase as gate opens, so it is critical not to exceed (270 OHMS) on this potentiometer.

- g) If failure is still present after transducer or potentiometer adjustment is made, proceed with # 5.
- 5) Check wiring for continuity between transducer or potentiometer and computer.
- 6) Check connections at computer (Rexroth)

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

Fixed hopper or Left gate + (P1-PIN10) Red

Left gate – (P1-PIN18) Black

Left gate wiper (P1-PIN6) Clear

Right gate + (P1-PIN11) Red

Right gate – (P1-PIN19) Black

Right gate wiper (P1-PIN7) Clear




Figure 5

1) Mounting bolts

2) Sensor adjustment screws (loosen and rotate sensor)

For further assistance call Etnyre service department at (1800-995-2116).

Problem # 7

Checking solid state gate transducer

REXROTH COMPUTERS (FIXED AND VARIABLE HOPPER)

Wiring Color Code:

- A)**RED – RED**
- B).....**BLUE – WHITE**
- C).....**BLACK – BLACK**

Adjustment Procedure:

- 1) Verify and make sure that gate is fully closed.
- 2) Test with wiring and sensors still connected (adapter available from Etnyre Part # 7050350).
- 3) Check voltage on the red wire-transducer input voltage (5 VDC) not adjustable. Ground using black wire terminal.
- 4) Check voltage on the blue wire-transducer signal (0.5-1.5 VDC) ideal setting is (1.0 VDC) ground using black wire terminal.
- 5) Re-calibrate (null/scale) gate calibrations in computer set-up if adjustment made

(See figure # 5 for proper adjustment procedure).

material will need to be re-calibrated if transducer is adjusted

- 7) Move transducer to simulate the gate opening, watch the transducer signal voltage as you actuate the transducer, the voltage should increase as the gate opens by 3 VDC over a 4-inch gate opening. Ensure that the signal is smooth and there is no interruption in the sweep of the transducer.

(Transducer signal output voltage examples).

Transducer range detached from unit (0-5 VDC)

Transducer range attached to gate assembly (3 VDC)

(Example: If signal voltage is 1 VDC with gate fully closed, voltage with gate fully open should not exceed 4 VDC.)

Problem # 8

Gates open / close faster than other side

- 1) Enter computer set-up. Hold down the calibrate switch and turn ignition switch to ACC or on position, release switch after alarm sounds (3) three times.
 - a)Scroll thru using the scroll switch until “right gate open” appears. This is the amount of power (amps) that it takes to energize and operate the gate. The higher the amps, the faster the gate operates. This number should not exceed 1.2 amps or it can create gate fluctuation.
 - b) .Scroll to next screen “right gate closed” adjust if needed (1.2 amps max.).
 - c) Scroll to next screen “left gate open” adjust if needed (1.2 amps max.).
 - d) ...Scroll to next screen “left gate closed” adjust if needed (1.2 amp max.).

On machines that have (1) one fixed hopper, the left gate open/close controls the gate speed.

On Variable width machines that have (2) two hoppers that both spread backwards these speeds can be the same. The gate hold, gate shut hold and the spread roll timer are the components that are instrumental in the control of the material stagger (straight line start/stop). Gate fluctuation could occur on these units if the open/close amps are not the same or similar.

On Variable width machines that have (1) one hopper that spreads backward and (1) one hopper that spreads forward, these numbers are instrumental in the timing of the material stagger (straight line start/stop).

If adjusting the gate speeds and the amps does not correct the problem, proceed with # 2

- 2) Check and verify hydraulic pressure on gate relief valve(s).
- 3) Check wiring connections at gate valve.
- 4) Check connection at the Harting (HON) connector mounted on the left outside conveyor rail. Variable width units the harting (HON) connector for the right side is mounted under the right conveyor above the right front tire.

Problem # 8 continued

5) Check output to gate valve.(amp output should match the output threshold set in the computer for gate open / close).

Gate valve connector - terminal (1) Red wire – power to valve
terminal (2) Black wire – ground

6) Check computer connections

COMPUTER CONNECTION IDENTIFICATION ON PAGE # 25

(P4-PIN 5) Right gate open solenoid (+)

Ground post (-)

(P4-PIN 6) Right gate close solenoid (+)

Ground post (-)

(P4-PIN 3) Left gate open solenoid (+)

Ground post (-)

(P4-PIN 4)Left gate close solenoid (+)

Ground post (-)

Problem # 9

Air gates out of adjustment (very loud noise as master power is turned on / off).

- 1) Identify if air gate(s) are out of adjustment or hydraulic gate buss arm(s) is not operating properly ...air gate problem go to #2
...hydraulic gate buss arm problem go to #3
- 2) Adjust air gates
 - a) Back off hydraulic gate arm adjustment screws between all hydraulic gate buss arms and air gates. (see figure # 6)
 - b) Adjust air gate adjustment screws (see figure # 6) to achieve a uniform gap of 1/16" across the spreadroll. Insure that there is air pressure applied to the gate forcing it closed during this adjustment.
 - c) Check all buss arm asm bolts to make sure that they are tight, (see figure # 6) replace any bent or broken bolts.
 - d) Calibrate gate (null/scale) in computer set-up. Proceedure for setting (null/scale) can be found in operation manual for machine. Gate transducer may need to be adjusted if you cannot achieve proper calibration.
 - e) With machine running and hydraulic pressure applied to hydraulic gate buss arm, turn air gate master power (ON) turn all individual air gate switches (ON) and allow air gates to open to hydraulic gate buss arm.
 - f) Adjust hydraulic gate buss arm adjustment screws and force air gates to close till the air gate adjustment screws touch and stop movement. do not force screws past its contact with the stop because it can change the gate transducer setting and hydraulic gate arm position. (repeat proceedure on each individual gate)
 - g) Repeat step (2d) to verify null is still at (0.00) and scale is at (4.00).
- 3) Adjust hydraulic gate buss arm.
 - a) Calibrate gate (null/scale) in computer set-up. Proceedure for setting (null/scale) can be found in operation manual for machine. Gate transducer may need to be adjusted if you cannot achieve proper calibration.
 - b) Refer to problem # 7 for gate transducer adjustment, if needed.




Figure 6

- 1) Air gate adjustment screw*
- 2) Hydraulic gate buss arm adjustment screw*
- 3) Buss arm asm bolt*

Problem # 10

Spreadroll speed fluctuating.

- 1) Check auxiliary stand-by pressure. If the stand-by pressure is too low the pump will not come on stroke quick enough, causing not enough pressure and flow will be supplied to the spread roll.

Check applicable chart for proper stand-by pressure. Procedures for adjusting stand- by pressure available in operation manual for machine.

- 2) Check and adjust speed of spread roll (RPM) at flow control cartridge.

On standard hopper units this cartridge is located in the gate/spread roll manifold (check applicable chart for proper RPM.) located in operation manual for machine.

On variable width hopper units this cartridge is located in the auger/spread roll manifolds. Left and right spreadrolls have separate cartridges. Check applicable chart located in the operation manual for the machine,for proper spreadroll RPM.

If the adjustment of spread roll RPM made in step 1 & 2 does not correct the problem, proceed with step # 3

- 3) Remove and inspect spread roll flow control cartridge for contamination or debris.

If no contamination is found or problem is not corrected, proceed with step #4.

- 4) Monitor auxiliary stand by pressure. Procedure for checking stand-by pressure is located in the operations manual for machine. Watch to see if spread roll speed follows the pressure (Example: as the pressure decreases the spread roll speed decreases etc.)

If this problem exists proceed to step #5.

- 5) Remove load sense checks (2) and inspect for contamination or debris (worn spring or pitted seat assembly).

Load sense check location:

On standard hopper units, the load sense checks (2) are located on the top of the conveyor manifold. (See figure # 7)

On variable width hopper units, the load sense checks (2) are located on the top of the auger/spread roll manifolds.(See figure # 8)




Figure 7

- | | |
|----------------------------|----------------------------|
| 1) Conveyor manifold block | 4) 12 VDC Coil |
| 2) Rt Conv Speed Control | 5) Load Sense Check Valves |
| 3) Lt Conv Speed Control | |




Figure 8

- | | |
|--------------------------------|----------------------------|
| 1) 12 VDC Coil | 3) Load Sense Check Valves |
| 2) Lt Spreadroll Speed Control | 4) Lt Auger Speed Control |

Problem # 11

Hydraulic Stand-by (load sense) pressure is fluctuating (needle not steady on gauge)

* This happens when the volume of oil present in the load sense system is too great, due to a missing or contaminated orifice or load sense check valve.

1) Check the orifice in load sense line fitting(s) attached to auxiliary hydraulic pump(s) load sense compensator valve.(see figure 9 item 3).

a) Check to insure that the orifice is installed in fitting (set screw installed inside fitting with .040 hole drilled in it).

b) Check the orifice for contamination

c) Verify the orifice size (.040)

2) Check the compensator operation to ensure that pressure is responding to demand of hydraulic system. Procedure for checking stand-by pressure is in the operation manual for machine.

* Bad or contaminated load sense check valves can cause erratic stand-by pressures. (see figure 7 & 8 to identify location of load check valves).

a) Check and/or set the stand-by pressure. With the engine shut off, remove the load sense lines from the compensators and cap them off. (see figure 9 item 4,5,6& 7) for the location of the lines. Check and set stand-by pressure using correct procedure in operation manual for machine. If proper stand-by pressure is obtained and remains steady with no fluctuating, proceed with step (b). If proper stand-by pressure is not achieved, possible pump and/or compensator problem.

b) Attach the load sense lines one at a time to determine which hydraulic manifold block has a contaminated or bad load sense check valve.

c) Check load sense check valve(s) for contamination, replace if needed.





Figure 9



- 1) Load Sense Adjustment
- 2) Main Pressure Adjustment
- 3) Load Sense Fitting w/ Orifice
- 4) Load Sense Jumper Hose between compensators
- 5) Hose to load sense port on Lt hopper manifold block
- 6) Hose to load sense port on conveyor manifold block
- 7) Hose to load sense port on Rt hopper manifold block

Verify routing of hoses (5,6&7) to insure correct hydraulic manifold is identified.

- * Standard hopper units will only have (1) auxiliary pump and (1) load sense line going to the conveyor manifold block. (load sense line between the conveyor block and the gate / spreadroll manifold block, will have to be removed and capped to isolate conveyor block. Each block has a "LS" stamped on the block to identify port)

Problem # 12

Overlap or streak in center when hoppers are fully extended.

This problem is adjustable as follows:

If the material is heavy in the middle and a overlap is present, the gate cut-off plate needs to be adjusted by sliding it in the hopper further (adjust both sides evenly). See figure # 10.

If the material is leaving a void or streak down the center of the road, first adjust cut-off plate by sliding it out of the hopper further. See figure # 10. If the cut-off plate cannot be adjusted any further, adjust the hopper (in/out) cylinder at the rod end of the cylinder. (adjust both sides evenly). See figure # 11.




Figure # 10




Figure # 11

Problem # 13

No gradability

- 1) Verify grade of incline. (Is grade too steep for machine to climb).
All % calculations with combined weight of (chipsreader / dump truck / aggregate) 80,000 lbs. Max.

Engine R.P.M. @ 2200 Computer speed set-point F.P.M. @ 200

2Wheel Drive – 6-8%

4Wheel Drive with 107cc motors 8-12%

4Wheel Drive with 160cc motors 12-18%

Motor size (cc) stamped on tag, attached to top of drive motor.

If % of grade is acceptable proceed with # 2

- 2) 2Wheel Drive Machines
 - a) Disconnect the electrical connector attached to the front drive hydraulic motor servo (secure wire).
 - b) Test unit on grade with 80,000 lbs.
- 3) 4Wheel Drive Machines
 - a) Disconnect the electrical connector attached to both front and rear drive hydraulic motor servos. (secure wires)
 - b) Test unit on grade with 80,000 lbs.

If disconnecting servo connectors allows machine to pull the grade, reconnect servos one at a time, and test unit to identify which motor servo is causing problem. (servo is receiving power that is changing the position of the internal swash plate of the hydraulic motor).

If disconnecting hydraulic motor servo connectors does not correct or improve performance proceed with # 4.

Procedures for checking hydraulic pressures can be found in operation manual for machine.

- 4) Check and verify hydrostat priority override (POR) hydraulic pressure.
- 5) Check and verify hydrostat main hydraulic pressure (FWD).
- 6) Check and verify hydrostat main hydraulic pressure (REV).

Problem # 14

Auxiliary hydraulic pressure will not relieve

Other Problems affected:

#5 Hydraulic oil temperature alarm

Problem is found during the process of checking pressures of the auxiliary hydraulic pumps #2 & 3. Pump #2 is fixed head unit.

The main pressure must relieve after checking main pressure or auxiliary pump will not de-stroke which creates heat and torque loss of engine and hard start condition if shut off between use.

To correct the problem:

- Shut off machine.
- Close and shut off main hydraulic suction valve.
- Locate and cap off case drain at pump.
- Remove compensator from hydraulic pump(s).
- Remove load sense compensator cartridge.
- Locate allen head 2mm (orifice) inside housing (see Figure 12)




Figure 12

- Remove orifice.
- Clean out orifice with strand of primary wire or torch cleaning kit (if small enough).
- Re-install orifice.
- Re-install cartridge.
- Re-install compensator.
- Uncap and reinstall case drain hose.
- Open suction valve.
- Install air regulator to hydraulic tank through vent filter connection.
- Apply 3 - 5 lbs to hydraulic system to push any trapped air in hydraulic system out.

Start machine and operate all functions to ensure hydraulic oil circulation.

Check and adjust pressures. Procedure located in operation manual for machine. *Be sure to have correct manual.*

Check to see if pressure relieves after main pressure is achieved.

If unable to adjust pressures on pump - pump may have sustained damage due to previous condition (won't stroke).

Isolation of pumps will be necessary to find out which pump is affected.

Problem # 15

Gates will not operate (Hydraulic buss bar)

- 1) Make sure that gate arming switches are turned (ON). Switches are located on operator's panel behind joystick.
- 2) Check (all) fuses or circuit breakers, including making sure there is power to both sides of fuse holder asm or circuit breaker asm.
- 3) Press gate override button and test gate operation.
 - If gate operates with override, there is a possible electrical issue. (Refer to # 5 and #6)
 - If gate doesn't operate with override, there is a possible hydraulic issue. (Refer to # 4)
- 4) Check hydraulic gate valve operation, override spool asm manually to test operation.
 - If gate operates with mechanical override, (Refer to #5)
 - If gate doesn't operate with mechanical override, (Refer to Operators Manual for instructions on testing hydraulic pressures).
- 5) Check gate pot / transducer adjustments.(refer to Problem # 6 and #7)
- 6) Check gate null / scale calibration (Refer to operation manual for correct procedure.
- 7) 7) Check joystick center roller micro switch / activating yes or no
- 8) 8) Check power across gate switch in joystick handle / activating yes or no.
- 9) 9) Check relays #2, #3,and #4, for proper operation
 - #2 relay activates when joystick is pushed out of neutral and micro switch connects, then relay #3 and #4 are allowed to activate with arming switches (ON), and gate switch (ON)
 - #3 relay activates the LH gate
 - #4 relay activates the RH gate
 - Make sure that the gate arming switches are (ON)

Note:

Service Screens (see operators manual) can be used to monitor most systems as they are being activated by the switches, and also being recognized by the controller and telling you (Active) or (De-active) on the display. You can select the individual screen of function you wish to monitor.

Note:

RH gate uses a gate hold feature. This is operated or changed in the computer set-up screens, and is utilized to achieve a straight line start when beginning to spread rock with a Variable Hopper ChipSpreader. This feature may also not allow gate to operate if unit is parked and operator is trying to cleanout or leave a pile for handwork.

If the (FPM) is malfunctioning, or not working the hold feature doesn't work and the RH gate will not open. Disabling the gate hold to (0) in the setup screens, will allow the RH gates to operate in manual mode.

Problem # 16

Starter Cranks But Does Not Start

- 1) Does the information display show (ENGINE CAN) meaning no can buss communication to display. (If / Yes) go to # 2
- 2) Check E-Stop button to make sure it was not bumped or pushed in. (twist it to pop out and release).
- 3) Cummins QSB and Tier 3 have an Engine Controller that requires power to start engine. Older units with B & C series engines have mechanical injector pumps and no engine controllers.
- 4) Check fuses for Cummins Engine (ECM) Controller and operations. These fuses are located near the power and ground distribution hub at the right rear corner of the Cummins engine. There may be as many as (6) depending on the size of the Cummins engine.

Verify fuse size and connections with schematic for the machine.

* Install replacement fuse with one no larger than the one removed.

Note: If unit is equipped with inline, yellow rubber insulated type fuse holders with glass fuses inside, the following procedure is recommended:

Pull fuse holder apart and make sure the ring is over the end of fuse. (Not just touching the end of the metal part of the fuse) this will give 12 vdc at the Cummins computer until there is a load placed on circuit.

Make sure the ring is tight and secure, with a good solder joint at the wiring end.

Inspect all connections: clean / repair / replace as needed

- 5) Check E-stop Switch connections , possible connection issue on switch for the fuel solenoid.
- 6) Check for issue with fuel solenoid on Cummins engine.

Problem # 17


Emergency Driveline Disengage Procedure

This procedure can be used to move your machine out of the middle of the road, when a rare breakdown occurs that disables the machine from moving. (Rexroth RC Computer).

1. Install (2) 04MB x 04MJ fittings, Etnyre # 9410200, (1) in each test port of the high pressure distribution block bolted to the side of the pump. This block connects the main drive hydraulic hoses going out to the drive motors. (Remove 04MB plug and install new fitting on both sides of pump)
2. Install (1) 04 x 65 inch hydraulic hose with 04FJX fittings, Etnyre # 3181497 across between fittings installed. (This creates a loop on the drive system without hydraulic oil flowing thru pump and relief system).



3. Disable or release the park brake unit (mounted in front of drive motor on front axle)



4. If the engine of the machine does not run, or there is an issue with the pump that supplies pressure to release the parking brake, a port-a power will have to be modified with a 04 FJX connection to attach to parking brake unit and apply pressure to release the park brake unit. (Approximately, 280-400 psi required)

5. In the event the engine runs and you are able to release the park brake unit, only loop hose is required, along with an operator to release the park brake. This can be done by placing the controls in drive mode and pushing the joystick in the direction of movement also steering the machine if needed while very slowly moving machine off the road or loading on to a transport trailer.


Note:

This procedure is for emergency situations only

This procedure is only to move machine extremely slow (crawl) your machine off the road or to slowly load machine on to transport trailer.

This procedure is not intended for travel or moving machine a long distance (damage could occur if not done correctly)

Computer Wiring connections



Computer Wiring Connections




Figure 13. Computer Wiring Connections

MDC Faults with version 3-52 software

Invalid Reset

- Cause of fault
 - a) Invalid reset occurs when some part of the MDC resets without a reset to the CPU (such as the output drivers).
- Possible fix
 - a) This is typically an internal fault. Rexroth has found on the bench that, if three or four of the following pins are shorted to ground, an invalid reset will occur.
 - P3-pin 11, P3-pin 12, P3-pin 13 and P3-pin 14
 - b) Check wiring to back light of display for short or grounding out.

Invalid Speed

- Cause of fault

The speed feedback is greater than 2500 FPM
- Possible fix

Bad speed pickup or noise on the sensor line

Internal Voltage

- Cause of fault

One of the regulated voltages goes out of range. The only regulated voltage we have access to is the +5 volt supply.
- Possible fix

We use the +5 volt supply for the old displays, the joystick and the gate pot power. If the 5 volts is shorted to ground this fault will trip. If one of our circuits draws more than 150 miliamps (old display) this will also trigger the fault.

Invalid Program

- Cause of fault

Occurs if the program is not loaded properly to the MDC or if parts of the program become corrupt.
- Possible fix

Reload program should fix the problem.

Joystick Microswitches

The joystick microswitches do cause a fault to be written to the display, but if the MDC does not see a microswitch signal where it thinks it should, the machine will not move. If the reverse microswitch is not working properly the machine will not go in reverse. This can typically be mitigated by adjusting the microswitch(s) to actuate quicker with change in joystick position. See Figure 14.

Machine comes to stop while moving

If you move the joystick back to neutral then forward and machine moves again.

Adjust neutral microswitch up so switch does not open when joystick is out of neutral.

See Figure 14.

Machine will not go in reverse

Make sure both microswitchs are actuated within first 5% of joystick movement. Adjust reverse microswitch to make sooner by moving switch down or adjust neutral to make sooner in reverse mode. See Figure 14.




Figure 14. Neutral and Reverse Switches

Joystick Adjustments:

Problem: Machine will not move forward and/or in reverse, after Rexroth Computer Update is completed.

Step # 1 Calibrate Joystick:

- Insure that joystick is in the neutral position
- Insure that machine is in the Park position
- Enter the Computer setup screens as follows:

With the ignition switch in the (OFF) position, push down and hold the (CAL) switch, as you turn the ignition switch to the (ON) position, wait for the warning alarm to “beep” 3 times and release the (CAL) switch. This will allow entry into the computer setup screens. To navigate the setup screens you will press the (SCROLL) switch down each time you wish to change screens. Change screens until the screen below appears.

```
SETUP:  JOYSTICK
ACTUAL:    0.0 %
```

To initiate the calibration process press the (CAL) switch down once and the screen will change to:

```
SETUP:  JOYSTICK
NEUTRAL: 0.0 VOLTS
```

Press (CAL) switch down once more and the screen will change to:

```
SETUP:  JOYSTICK
MAX FWD: 2.5 VOLTS
```

Move joystick forward to the full forward position, the voltage reading on the screen should increase to 4.0 to 4.9 volts. Press the (CAL) switch down to calibrate the full forward position and the screen will change to:

```
SETUP:  JOYSTICK
MAX REV: -2.5 VOLTS
```

Move joystick back to the full reverse position, the voltage reading on the screen should decrease to -4.0 to -4.9 volts. Press the (CAL) switch down to calibrate the full reverse position, return the joystick to the neutral position and the screen will change to:

```
SETUP:  JOYSTICK
ACTUAL:    0.0 %
```

Using the (SCROLL) switch, navigate thru to the last screen to save the joystick calibration this screen will appear as:

SETUP: SAVE AND EXIT
PRESS SAVE TO STORE

Press (SAVE) button to save the joystick calibration and it will automatically return to the operation screen.

Retest the machine using the same criteria as the update, if the machine still does not want to move in forward and/or reverse, continue to step # 2.

Step # 2 Adjusting Joystick Micro Switches:


- insure that the joystick is in the neutral position
- insure that the machine is in the Park position

Turn the ignition switch (ON) and monitor the display screen after the computer boots up. The operation screen will appear as shown (however) the app rate, type of material and speed set-point may differ.

18.0	3/8	300
18/90	CHIPS	FPM

Monitor display and locate the speed set-point in the upper RH corner of the screen

18.0	3/8	0
18/90	CHIPS	FPM



Move joystick forward (out of neutral) the speed set-point should change to (0), this acknowledges that the drive mode has initiated. If the set-point does not change to (0), adjustment to the neutral switch (Figure A) may be required to move the micro switch closer to the activating cam on the joystick. NOTE: this circuit must be completed within 5% of the joystick movement.

Move joystick in reverse (out of neutral) the speed set-point should change to (0), this acknowledges that the drive mode has initiated. If the set-point does not change to (0), adjustment to the neutral (Figure A) and/or reverse (Figure B) switch may be required to move the micro switch closer to the activating cam on the joystick. NOTE: Both circuits must be completed within 5% of the joystick movement.

Wiring at the Joystick Switches

Neutral switch (see Figure 15)

Purple wire attached to the N/C normally closed connection on the micro switch.

This wire must lose 12VDC within 5% of the joystick movement in forward and reverse

Reverse switch (see Figure 15)

Red/white wire (white wire after update harness is added) attached to the N/O normally open connection on the micro switch. This wire must receive 12VDC within 5% of the joystick movement in reverse

Loosen and adjust micro switches as needed so that the drive mode initiates in forward and reverse.




Figure 15. Neutral and Reverse Switches

Notes

[illegible]